CHAPTER 91

WATER METERS

91.01 Purpose 91.02 Water Use Metered 91.03 Fire Sprinkler Systems – Exception 91.04 Location of Meters 91.05 Meter Setting 91.06 Meter Repairs 91.07 Right of Entry

- **91.01 PURPOSE.** The purpose of this chapter is to encourage the conservation of water and facilitate the equitable distribution of charges for water service among customers.
- **91.02 WATER USE METERED.** All water furnished customers shall be measured through meters furnished by the City and installed by a plumber. All meters shall be owned and maintained by the City.
- 91.03 FIRE SPRINKLER SYSTEMS EXCEPTION. Fire sprinkler systems may be connected to water mains by direct connection without meters under the direct supervision of the Superintendent. No open connection can be incorporated in the system, and there shall be no valves except a main control valve at the entrance to the building which must be sealed open.
- **91.04 LOCATION OF METERS.** All meters shall be so located that they are easily accessible to meter readers and repairmen and protected from freezing.
- **91.05 METER SETTING.** The property owner shall provide all necessary piping and fitting for proper setting of the meter including a globe type valve on the discharge side of the meter. Meter pits may be used only upon approval of the Superintendent and shall be of a design and construction approved by the Superintendent.
- **91.06 METER REPAIRS.** Whenever a water meter is found to be out of order the Superintendent shall have it repaired. If it is found that damage to the meter has occurred due to the carelessness or negligence of the customer or property owner, then the property owner shall be liable for the cost of repairs.
- **91.07 RIGHT OF ENTRY.** The Superintendent shall be permitted to enter the premises of any customer at any reasonable time to read, remove, or change a meter.